

Multi Plate Repair Parts



PART NO.	C.COVER ①	P.PLATE ②	I.M.PLATE ③	DISC Assy ④-A	DISC Assy ④-B	DISC Assy ④-C	SPLINED HUB	D.BOSS SET	F/W RING ⑤	FLYWHEEL ⑥	COVER BOLT SET ⑦⑨	PIVOT RING ⑩	FLYWHEEL BOLT ⑪	SPECIAL SLEEVE OR BEARING
ET01SD	CT01S	---	IM07	DT01D	DT01D	---	---		---	FT01T	BS09	---	---	---
ET02SD	CT01S	---	IM07	DT01D	DT01D	---	---		---	FT03T	BS09	---	---	---
ET03SD	CT01S	---	IM07	DT02D	DT02D	---	---		---	FT01T	BS09	---	---	---
FM012HBL														
FM012HD	CM02H	PP02	IM01	DM16DA	DM16DB	---	---		FR01	FM13	BS05	PR01	BF08	---
FM012SD	CM02S	PP02	IM01	DM16DA	DM16DB	---	---		FR01	FM13	BS05	PR01	BF08	---
FM013HB	CM02H	PP02	IM02	DL03R	DL03R	DL03R	CH10		FR01	FM13	BS05	PR01	BF08	---
FM022HBL														
FM022HD	CM29H	PP02	IM01	DM16DA	DM16DB	---	---		FR01	FM13	BS05	PR01	BF08	---
FM022SD	CM03S	PP02	IM01	DM16DA	DM16DB	---	---		FR01	FM13	BS05	PR01	BF08	---
FM022SDL	CM34S	PP09	IM05	DM35DA	DM35DB			DB02		FM24	BS05	PR02	BF08	---
FM023HB	CM03S	PP02	IM02	DL03R	DL03R	DL03R	CH10		FR01	FM13	BS05	PR01	BF08	---
FM023HHB	CM29H	PP02	IM02	DL03R	DL03R	DL03R	---		FR01	FM13	BS05	PR01	BF08	---
FM032XD	CM54H	PP37	IM01	DM16DA	DM16DB				FR01	FM13	BS05		BF08	---
GT01SD	CT01S	---	IM07	DT02D	DT02D	---	---		---	FT02T	BS09	---	---	---
GT04SD	CT01S	---	IM07	DT04D	DT04D	---	---		---	FT02T	BS09	---	---	---
GT04XD	CT01H		IM07	DT05D	DT05D					FT02	BS09			
HM012SD	CM08S	PP04	IM01	DM19DA	DM19DB	---	---		FR01	FM14	BS05	---	---	---
HM022SR	CM09S	PP05	IM04	DM22RA	DM22RB	---	---	DB05	---	FM15	BS05	---	---	---
HM032SBL	CM49S	PP06	IM05	DL01R	DL01R	---	CH11	DB02	---	FM55	BS05	---	---	---
HM042SR	CM09S	PP05	IM04	DM23RA	DM23RB	---	---	DB05	---	FM15	BS05	---	---	---
HM052HBL	CM38S	PP27	IM05	DL01R	DL01R		CH11	DB02		FM46	BS05			
MM022HBL	CM43H	PP09	IM05	DL01R	DL01R		CH07	DB02		FM23	BS05	PR02		
MM022SBL	CM35S	PP09	IM05	DL01R	DL01R		CH07	DB02		FM23	BS05	PR02		
MM022HD	CM06H	PP02	IM01	DM13DA	DM13DB	---	---		FR01	FM12	BS05	PR01	---	---
MM022SD	CM06S	PP02	IM01	DM13DA	DM13DB	---	---		FR01	FM12	BS05	PR01	---	---
MM023HR	CM06H	PP02	IM02	DL03R	DL03R	DL03R	CH16		FR01	FM12	BS05	PR01	---	---
MM023SR	CM06S	PP02	IM02	DL03R	DL03R	DL03R	CH16		FR01	FM12	BS05	PR01	---	---
MM062HD	CM06H	PP02	IM01	DM09DA	DM09DB				FR01	FM59	BS05	PR01		
MM062HBL														
MM062SBL	CM35S	PP09	IM05	DL01R	DL01R		CH07	DB02		FM60	BS05	PR02		
MM062SD	CM06S	PP02	IM01	DM09DA	DM09DB				FR01	FM59	BS05	PR01		
MM063HB	CM06H	PP02	IM02	DL03R	DL03R	DL03R	CH16		FR01	FM59	BS05	PR01		
MM063SB	CM06S	PP02	IM02	DL03R	DL03R	DL03R	CH16		FR01	FM59	BS05	PR01		
NM012HD	CM01H	PP01	IM01	DM01DA	DM01DB	---	---		FR01	FM01	BS05	---	BF01	---
NM012SD	CM01S	PP01	IM01	DM01DA	DM01DB	---	---		FR01	FM01	BS05	---	BF01	---
NM013HB	CM01H	PP01	IM02	DL03R	DL03R	DL03R	CH12		FR01	FM01	BS05		BF01	---
NM022SD	CM01S	PP01	IM01	DM01DA	DM01DB	---	---		FR01	FM02	BS05	---	BF08	---
NM032HD	CM01H	PP01	IM01	DM01DA	DM01DB	---	---		FR01	FM03	BS05	---	BF03	---
NM032SD	CM01S	PP01	IM01	DM01DA	DM01DB	---	---		FR01	FM03	BS05	---	BF03	---
NM033HRW	CM01H	PP01	IM02	DL03R	DL03R	DL03R	CH12		FR01	FM03W	BS05	---	BF03	---
NM033HRWH	CM01H	PP01	IM02	DL03R	DL03R	DL03R	CH13		FR01	FM03W	BS05	---	BF03	---
NM033HRWT	CM01H	PP01	IM02	DL03R	DL03R	DL03R	CH14		FR01	FM03W	BS05	---	BF03	---
NM033SR	CM01S	PP01	IM02	DL03R	DL03R	DL03R	CH12		FR01	FM03	BS05	---	BF03	---
NM042HD	CM02H	PP02	IM01	DM01DA	DM01DB	---	---		FR01	FM03	BS05	PR01	BF03	---

Multi Plate Repair Parts



PART NO.	C.COVER ①	P.PLATE ②	I.M.PLATE ③	DISC Assy ④-A	DISC Assy ④-B	DISC Assy ④-C	SPLINED HUB	D.BOSS SET	F/W RING ⑤	FLYWHEEL ⑥	COVER BOLT SET ⑦⑨	PIVOT RING ⑩	FLYWHEEL BOLT ⑪	SPECIAL SLEEVE OR BEARING
NM042SD	CM02S	PP02	IM01	DM01DA	DM01DB	---	---		FR01	FM03	BS05	PR01	BF03	---
NM043SR	CM02S	PP02	IM02	DL03R	DL03R	DL03R	CH12		FR01	FM03	BS05	PR01	BF03	---
NM052HD	CM29H	PP02	IM01	DM01DA	DM01DB	---	---		FR01	FM04	BS05	PR01	BF03	---
NM052SD	CM03S	PP02	IM01	DM01DA	DM01DB	---	---		FR01	FM04	BS05	PR01	BF03	---
NM053SR	CM03S	PP02	IM02	DL03R	DL03R	DL03R	CH12		FR01	FM04	BS05	PR01	BF03	---
NM062SD	CM01S	PP01	IM01	DM01DA	DM01DB	---	---		FR01	FM05	BS05	---	---	---
NM063SR	CM01S	PP01	IM02	DL03R	DL03R	DL03R	CH12		FR01	FM05	BS05	---	---	---
NM092SD	CM01H	PP01	IM01	DM01DA	DM01DB				FR01	FM56	BS05		BF03	
NM093HB	CM01H	PP01	IM02	DL03R	DL03R	DL03R	CH12		FR01	FM56	BS05		BF03	
TM012SR	CM01S	PP01	IM03	DM04RA	DM04RB	---	---		FR02	FM06	BS06	---	BF04	RB01
TM032SD	CM04S	PP03	IM01	DM05DA	DM05DA	---	---		FR01	FM09	BS05	---	---	---
TM042SD	CM05S	PP03	IM01	DM07DA	DM07DA	---	---		FR01	FM09	BS05	---	---	---
TM043SR	CM05S	PP03	IM02	DL03R	DL03R	DL03R	CH15		FR01	FM09	BS05	---	---	---
ZM012HD	CM01H	PP01	IM01	DM09DA	DM09DB	---	---		FR01	FM10	BS05	---	BF07	---
ZM012SD	CM01S	PP01	IM01	DM09DA	DM09DB	---	---		FR01	FM10	BS05	---	BF07	---
ZM013HR	CM01H	PP01	IM02	DL04R	DL04R	DL04R	CH16		FR01	FM10	BS05	---	BF07	---
ZM013SR	CM01S	PP01	IM02	DL04R	DL04R	DL04R	CH16		FR01	FM10	BS05	---	BF07	---
ZM022HD	CM02H	PP02	IM01	DM09DA	DM09DB	---	---		FR01	FM10	BS05	PR01	BF07	---
ZM022SD	CM02S	PP02	IM01	DM09DA	DM09DB	---	---		FR01	FM10	BS05	PR01	BF07	---
ZM023HR	CM02H	PP02	IM02	DL04R	DL04R	DL04R	CH16		FR01	FM10	BS05	PR01	BF07	---
ZM023SR	CM02S	PP02	IM02	DL04R	DL04R	DL04R	CH16		FR01	FM10	BS05	PR01	BF07	---